


MC7000 & Traktor Pro 3 Mapping Install Notes

- [Mapping Setup](#)
- [Audio Setup – Windows](#)
- [Audio Setup – Mac](#)




Mapping Install

1. [Download](#) and unzip the MC7000 Traktor mapping .tsi file to your computer.
2. Power on the MC7000 and connect the USB to your computer.
3. Open **Traktor Pro 3**.
4. Open **Preferences**.
5. Click the **Import** button from the bottom of the window.
6. Select the MC7000 Traktor Mapping .tsi file.
7. Leave the default boxes checked like below and click **OK**.



8. Once loaded, select **Controller Manager** tab from the list.
9. Under **Device Setup** you'll want to ensure both the **In-Port** and **Out-Port** are set to **DENON DJ MC7000**.



10. Repeat this step for each of the 5 device mappings.


```
MC7000.MIXER.LIBRARY.FX - Generic MIDI (DENON DJ MC7000 (DENON DJ MC7000))
MC7000.DECK.1|A - Generic MIDI (DENON DJ MC7000 (DENON DJ MC7000))
MC7000.DECK.2|B - Generic MIDI (DENON DJ MC7000 (DENON DJ MC7000))
MC7000.DECK.3|C - Generic MIDI (DENON DJ MC7000 (DENON DJ MC7000))
MC7000.DECK.4|D - Generic MIDI (DENON DJ MC7000 (DENON DJ MC7000))
```

11. Mapping setup complete. Proceed to Audio Setup below.


Audio Setup - Windows

Download and **Install** the latest Windows driver from the Downloads Software Download page at: <https://www.denondj.com/downloads>

1. Open **Traktor Pro 3**.
2. Open **Preferences**.
3. Choose **DENON DJ MC7000 ASIO** as your **Audio Device**.
4. Set your desired **Sample Rate**, and **Buffer Size**.



5. Adjust your **Output Routing** to match below:



6. Once these settings are correct close the **Preferences** window.
7. For the best mixing experience, set your headphone monitor controls as below.




8. Setup complete.


Audio Setup – Mac

The MC7000 is Class Compliant on Mac and does not require additional audio drivers. Follow the settings below to complete the Audio Setup.

1. Open **Traktor Pro 3**.
2. Open **Preferences**.
3. From Audio Setup, choose **DENON DJ MC7000** as your **Audio Device**.



4. Set your desired **Sample Rate**, and **Buffer Size**.
5. Adjust the **Output Routing** to match below:



6. Once these settings are correct close the **Preferences** window.
7. For the best mixing experience, set the internal headphone monitor controls as below.



8. Setup complete.